




Data, weights and dimensions are not binding for the manufacturer, who reserves the right to bring changes as he sees fit.



Spare parts: When ordering spare parts, please specify type of sprinkler and code number.

Code	Fig No.	Qty	Description	Code	Fig No.	Qty	Description	Code	Fig No.	Qty	Description
140301kit	01	1	Sprinkler body	140323	23	3	Slow speed gear	140355	55	2	Inversion ring
140300G	02		Complete gearbox	140326	26	1	O-ring	140356	56	1	Cover for lever
140302	2	1	Gearbox	140328	28	3	O-ring	140356a	56a	1	Screw
140303	3	1	Gearbox cover	140329	29	1	O-ring	140356b	56b	1	Nut 4MA
140304	4	1	Body support	140330	30	1	Cam	140358kit	058	1	Central shaft
140305	5	1	Crown	140331	31	1	Elastic pin	140359kit	059	1	Inversion fork
140305a	5a	4	Screw	140332	32	1	Shafting bar	140359a	59a	1	Pin for fork
140305b	5b	1	Ring body support	140333	33	1	Shafting bar cover	140360	60	1	Spring house
140305c	5c	1	Ring	140113a	35	1	O-ring	140361	61	1	Inversion spring
140306	6	1	U-packing crown	140335a	35a	1	O-ring	140362kit	062	1	Vice for inversion lever
140112	7	52	Sphere	140336	36	3	Main Nozzle	140362a	62a	1	Pin for vice
140308	8	1	Threaded body support	140117	37	1	Nozzle lock ring	140363	63	1	Screw
140309	9	1	Endless screw	140338	38	1	Packing for nozzle O-ring	140364a	64a	1	Spring for bolt
140309a	9a	1	Grub screw	140339kit	039	1	Jet-breaker	140365	65	1	Inversion lever bearing
140309b	9b	1	Plug	140340	40	1	Pipe-head	140366	66	1	DU-Bearing for gearbox
140310kit	010	1	Threaded bearing	140341	41	1	Jet breaker spring	140367	67	1	DU-Bearing
140310akit	010a	1	Internal bearing	140342kit	042	1	Complete jet-breaker lever	140368	68	2	Grease nipple
140310b	10b	2	Washer	140342a	42a	1	Screw	140369	69	1	Gearbox support
140310c	10c	1	Grub screw	140343	43	1	Screw for lever	140370	70	1	Screw 8x25
140311	11	1	Pinion bearing	140344	44	1	Nut for lever	140371	71	1	Nut
140313	13	1	Threaded ring for crown	140345	45	1	Principal pipe	140372	72	2	Grub screw
140313a	13a	1	Screw	140346	46	4	Screw	140373a	73a	1	Elastic pin
140314	14	2	Ball bearing ring	140347	47	1	Locking ring for pipe	140374	74	1	Plug
140315	15	1	Propeller	140347a	47a	1	O-ring	140374a	74a	1	Washer
140316	16	1	Endless screw	140348	48	1	Secondary pipe	140375	75	4	Washer
140316a	16a	1	Grub screw	140348a	48a	1	O-ring	140376	76	1	Fastener Ring
140317kit	017	1	Bearings house	140350	50	1	Secondary nozzle	140377	77	1	Spring
140318	18	1	Blind bearing	140351	51	1	Ferrule	140397kit	078	1	Complete Unlocking Kit
140319	19	1	Toothed wheel	140352	52	2	Screw	140378b	78	1	Spacer
140320	20	1	Gearbox pinion	140353	53	6	Washer grower d.6	140379	79	1	Shafting bar
140320a	20a	2	Pin for pinion	140353a	53a	2	Nut	140379a	79a	1	Washer
141422kit	022	1	Planetary	140354	54	1	Washer	140379b	82	1	Prisoner