


Data, weights and dimensions are not binding for the manufacturer, who reserves the right to bring changes as he sees fit.

**2 Speed**



**Spare parts:** When ordering spare parts, please specify type of sprinkler and code number.

Code	Fig No.	Qty	Description	Code	Fig No.	Qty	Description	Code	Fig No.	Qty	Description
140301kit	01	1	Sprinkler body	144119	19	1	Crown	140345	45	1	Principal pipe
140302	2	1	Gearbox	140319a	19a	1	Spring	140347	47	1	Locking ring for pipe
140300G2ki	02	1	Complete gearbox	144120	20	1	High speed pinion	140347a	47a	1	O-ring
144103	3	1	Gearbox cover	140320a	20a	2	Pin for pinion	144148	48	1	Secondary pipe
144103a	3a	1	Cover	141522kit	022	1	Planetary	140348a	48a	1	O-ring 1
140304	4	1	Body support	140322a-kit	022a	1	Second planetary	140350	50	1	Secondary nozzle
140305	5	1	Crown	144123	23	6	High speed gear	140351	51	1	Ferrule
140305a	5a	4	Screw	144123a	23a	4	Stud bolt	144152	52	4	Screw
140305b	5b	1	Ring body support	140324kit	024	1	Pinion	140353	53	8	Washer grower d. 6
140305c	5c	1	Ring	140324a	24a	1	Screw 6x30	140353a	53a	4	Nut
140306	6	1	U-packing crown	140137a	25a	1	Nut	140354	54	2	Washer
140112	7	52	Sphere	140326	26	1	O-ring	140355	55	2	Inversion ring
140308	8	1	Threaded body support	140328	28	3	O-ring	140356	56	1	Cover for lever
140309	9	1	Endless screw	144128a	28a	1	O-ring	140356a	56a	1	Screw
140309a	9a	1	Grub screw	140329	29	1	O-ring	140356b	56b	1	Nut 4MA
140309b	9b	1	Plug	140329a	29a	4	Washer inox	140358kit	058	1	Central shaft
140310kit	010	1	Threaded bearing	140330	30	1	Cam	140359kit	059	1	Inversion fork
140310a-kit	010a	1	Internal bearing	140331	31	1	Elastic pin	140359a	59a	1	Pin for fork
140310b	10b	2	Washer	144132	32	1	Shafting bar	140360	60	1	Spring house
140310c	10c	1	Grub screw	144133	33	1	Shafting bar cover	140361	61	1	Inversion spring
140311	11	1	Pinion bearing	140113a	35	1	O-ring	140362kit	062	1	Vice for inversion lever
140312	12	1	Gearbox central body	140335a	35a	1	O-ring	140362a	62a	1	Pin for vice
140313	13	1	Threaded ring for crown	140336	36	3	Main Nozzle	140363	63	1	Screw
140313a	13a	1	Screw	140337	37	1	Nozzle lock ring	140364a	64a	1	Spring for bolt
140314	14	2	Ball bearing ring	140338	38	1	Packing for nozzle O-ring	140365	65	1	Inversion lever bearing
144115	15	1	Propeller	140339kit	039	1	Jet-breaker	140366	66	1	DU-Bearing for gearbox
144116	16	1	Endless screw	140340	40	1	Pipe-head	140367	67	1	DU-Bearing
140316a	16a	1	Grub screw	140341	41	1	Jet breaker spring	140368	68	2	Grease nipple
140317kit	017	1	Bearings house	140342kit	042	1	Jet-breaker lever	140370	70	1	Screw
140317a	17a	1	Lever	140342a	42a	1	Screw	140371	71	1	Nut
140318	18	1	Blind bearing	140343	43	1	Screw for lever	140372	72	2	Grub screw

