



Data, weights and dimensions are not binding for the manufacturer, who reserves the right to bring changes as he sees fit.

**Spare parts:** When ordering spare parts, please specify type of sprinkler and code number.

Code	Fig No.	Qty	Description	Code	Fig No.	Qty	Description	Code	Fig No.	Qty	Description
145301kit	01	1	Complete Body	145328kit	028	1	Complete Head	145354	54	1	Arm Spring
145302kit	02	1	Complete External Body	145328a	28a	2	Screw	145355	55	1	Shaft For Regulator
145303n	3n	1	Body Support	145328b	28b	2	Nut	145356	56	1	Shaft
145304	4	1	Sector Ring Bearing/Brake	145329	29	1	Principal Pipe	140324a	57	1	Screw
145305	5	1	Internal Ring To The Body	145329a	29a	1	O-Ring	145358	58	1	Nut
145306kit	06	1	Complete Support	145330	30	1	Washer	145359	59	1	Spring
145308	8	22	Sphere	145331	31	1	Fastener Ring	145360	60	1	Brake Dowel Pin
145309	9	1	U-Packing	145332	32	2	Spacer For Inversion Shaft	145361	61	2	Inversion Ring
145310	10	4	Screw	145333kit	033	1	Complete Support	145363kit	063	1	Complete Plate
145310a	10a	2	Screw	145333	33	1	Arm Support	145364	64	2	Screw
145311kit	011	1	Complete Brake	145334	34	2	Screw	145365	65	1	O-Ring
145312kit	012	1	Complete Arm Support	140353a	35	4	Nut	145366	66	1	Bush
145312	12	1	Arm Support	145336kit	036	1	Complete Lever				
145312b	12b	2	Bushing	145336	36	1	Inversion Lever				
145313kit	013	1	Complete Arm	145337	37	1	Clamp For Inversion Lever				
145313	13	1	Arm	140363	38	1	Screw				
145314	14	1	Arm Shaft	145339	39	4	Screw				
145314a	14a	2	Locking Nut	140137a	40	10	Nut				
145315	15	1	Spoon	141941	41	1	Inversion Spring				
140363	15a	3	Screw	145342	42	2	Bearing				
145316	16	1	Nut	140329a	43	2	Washer Inox				
140117	17	1	Nozzle Locking Ring	145344	44	1	Reversing Lever Bar				
145318	18	3	Main Nozzle	145345kit	045	1	Complete Pin				
140338	19	1	Packing For Nozzle - Or	145345	45	1	Fork Lever				
145320	20	2	Ball Bearing	145346	46	1	Tapered Spring				
145321	21	2	Ball Bearing	145347	47	2	Bearing				
145322	22	1	Short Spacer	140374	48	1	Plug				
145323	23	1	Medium Spacer	140374a	49	1	Washer				
145324	24	1	Long Spacer	140370	50	2	Screw				
145325	25	2	Gasket For Arm Shaft	140371	51	2	Nut				
145326	26	1	Gasket For Inversion Shaft	145352	52	2	Knob				
145327	27	1	Gasket For Inversion Shaft	145353	53	1	Arm Stroke Regulator				