IB International Pty Ltd
PO Box 5481 Manly Qld 4179
Ph: 07 3348 8300 Fax: 07 3348 8900
Mob: 0408 379 619 Web: www.ibinternational.com.au

Funny

Part Circle



Full Circle



Spare parts: *When ordering spare parts, please specify type of sprinkler and code number.*

Data, weights and dimensions are not binding for the manufacturer, who reserves the right to bring changes as he sees fit.

Code	Fig No.	Qty	Description	Code	Fig No.	Qty	Description	Code	Fig No.	Qty	Description
			PART CIRCLE								FULL CIRCLE
142601kit	01	1	Sprinkler Body	142629	29	1	Pin For Lever	142501kit	01	1	Sprinkler Body
142501a	1a	1	Water Rectifier	142630	30	1	Pin For Lever	142501a	1a	1	Water Rectifier
142502	2	1	Arm	142531	31	1	Cap Split Pin	142502	2	1	Arm
142503	3	1	External Body	141825a	32	1	Spring	142503	3	1	External Body
142504	4	1	Internal Body					142504	4	1	Internal Body
142506	6	1	Shaft Washer					142506	6	1	Shaft Washer
142507	7	1	Arm Spring Cap					142507	7	1	Arm Spring Cap
142508	8	1	Arm Spring					142508	8	1	Arm Spring
142509	9	1	Spring Support					142509	9	1	Spring Support
142510	10	1	Friction Spring					142510	10	1	Friction Spring
142511	11	1	Friction Washer					142511	11	1	Friction Washer
142611a	11a	1	Teflon Washer					142512	11a	1	Teflon Washer
142512	12	1	Teflon Washer					142512	12	1	Teflon Washer
142513	13	1	Rubber Washer					142513	13	1	Rubber Washer
142513a	13a	1	Vulk Washer					142513a	13a	1	Vulk Washer
142514	14	2	Main Nozzle					142514	14	2	Main Nozzle
142517kit	017	1	Complete Jet Breaker					142517kit	017	1	Complete Jet Breaker
142517	17	1	Jet Breaker					142517	17	1	Jet Breaker
142517a	17a	1	Jet Breaker Screw					142517a	17a	1	Jet Breaker Screw
142618-19	18-19	2	Stopper Ring					142527	27	1	Knob
142619	019	1	Complete Inversion Ring					142528	28	1	Screw
142620kit	020	1	Primary Lever					142528a	28a	1	Locking Nut
142621kit	021	1	Secondary Lever					142531	31	1	Cap Split Pin
142622	22	1	Spring House					141825a	32	1	Spring
142623	23	1	Inversion Spring								
142625	25	1	Inversion Lever Cover								
142626	26	1	Inversion Screw								
141825a	26a	1	Spring								
142527	27	1	Knob								
142528	28	1	Screw								
142528a	28a	1	Locking Nut								