IB International Pty Ltd
PO Box 5481 Manly Qld 4179
Ph: 07 3348 8300 Fax: 07 3348 8900
Mob: 0408 379 619 Web: www.ibinternational.com.au

K1 teso 8°

Part Circle



Full Circle



Spare parts: *When ordering spare parts, please specify type of sprinkler and code number.*

Data, weights and dimensions are not binding for the manufacturer, who reserves the right to bring changes as he sees fit.

Code	Fig No.	No.	Description	Code	Fig No.	No.	Description	Code	Fig No.	No.	Description
			TESO PART CIRLCE	141825a	25a	1	Spring				
143801kit	01	1	Sprinkler Body	141826	26	1	Knob				
143802kit	02	1	Arm	141827	27	1	Screw				
141802a	2a	1	Arm Bearing	141827a	27a	1	Nut				
141803	3	1	External Body	141830	30	1	Cap Split Pin				
141804	4	1	Internal Body	141832	32	1	O-Ring				
141806	6	1	Shaft Washer	141834	34	1	Water Rectifier				
141807	7	1	Arm Spring Cap	141837	37	1	Jet Breaker Spring				
141808	8	1	Arm Spring	143738	38	1	Washer				
141809	9	1	Spring Support								
141810	10	1	Friction Spring								
141810a	10a	1	Friction Spring Cover								
141811	11	1	Friction Washer								
141812	11a	1	Teflon Washer								
141812	12	1	Teflon Washer								
141812a	12a	1	Vulk Washer								
141813	13	1	Rubber Washer								
141814	14	3	Main Nozzle								
141815kit	015	1	Complete Jet Breaker								
141815	15	1	Jet Breaker								
141816	16	1	Jet Breaker Screw								
141817	17	1	Inversion Ring								
143718kit	018	1	Complete Ring								
141817	18	1	Inversion Ring								
143819kit	019	1	Primary Lever								
143719a	19a	1	Pin For Lever								
143720kit	020	1	Secondary Lever								
143720a	20a	1	Pin For Lever								
143721	21	1	Spring House								
143722	22	1	Inversion Spring								
143724	24	1	Inversion Lever Cover								
143725kit	025	2	Inversion Screw								