IB International Pty Ltd
PO Box 5481 Manly Qld 4179
Ph: 07 3348 8300 Fax: 07 3348 8900
Mob: 0408 379 619 Web: www.ibinternational.com.au

Koala



Spare parts: *When ordering spare parts, please specify type of sprinkler and code number.*

Data, weights and dimensions are not binding for the manufacturer, who reserves the right to bring changes as he sees fit.

Code	Fig No.	No.	Description	Code	Fig No.	No.	Description	Code	Fig No.	No.	Description
	01	1	Sprinkler Body		33	2	Inversion Rings				
	1a	1	Water Rectifier		33a	2	1" Female Rings				
	2	1	Arm								
	3	1	External Body								
	4	1	Internal Body								
	6	1	Shaft Washer								
	7	1	Arm Spring Cap								
	9	1	Spring								
	10	1	¾ Female Body								
	11	2	Arm Beating Washer								
	12	1	Rubber Washer								
	12a	1	Washer								
	13	1	Nozzle								
	14	1	Spring Support								
	15	1	Spring Cap								
	16	1	Spring								
	18	1	Lever Pivot								
	19	1	Spring Support								
	20	1	Blocking Cap Cotter Pin								
	022	1	Complete Jet-Breaker								
	22	1	Jet-Breaker								
	23	1	Jet-Breaker Screw								
	24	1	Jet-Breaker Screw Spring								
	25	1	Screw								
	26	1	Nut								
	27	1	1" Female Body								
	28	1	Beating Lever								
	029	1	Complete Lever								
	29a	1	Lever Pin								
	30	1	Spring								
	31	1	Washer								
	32	1	Cotter Pin								