IB International Pty Ltd
PO Box 5481 Manly Qld 4179
Ph: 07 3348 8300 Fax: 07 3348 8900
Mob: 0408 379 619 Web: www.ibinternational.com.au

Zenith



Spare parts: *When ordering spare parts, please specify type of sprinkler and code number.*

Data, weights and dimensions are not binding for the manufacturer, who reserves the right to bring changes as he sees fit.

Code	Fig No.	Qty	Description	Code	Fig No.	Qty	Description	Code	Fig No.	Qty	Description
145401kit	01	1	Complete Sprinkler Body								
145402	2	1	Arm								
145403	3	1	External Body								
145404	4	1	Internal Body								
145406	6	1	Shaft Washer								
145407	7	1	Arm Spring Cap								
145408	8	1	Arm Spring								
145409	9	1	Spring Support								
145411	11	1	Teflon Washer								
145412	12	1	Rubber Washer								
145412a	12a	1	Vulk Washer								
145413	13	1	Main Nozzle								
145414	14	1	Jet Breaker Screw								
145415	15	1	Knob								
145416	16	1	Friction Spring								
145417	17	1	Secondary Nozzle								
145418	18	1	Friction Cap								
145420	20	1	Cap Split Pin								
145423	23	1	Wedge								
145424	24	1	Washer								
145425	25	1	Screw								
140137a	25a	1	Nut								
141837	26	1	Spring								
145427	27	1	Water Rectifier								